

ASCENT ASULF

PART#	PARTS NAME	PART#	PARTS NAME	PART#	PARTS NAME
1071787	Drag Knob	1066847	Ball S/P Shaft	72107	O/S Slider S/C
72002	Drag Nut	70206	Ball S/P Cover S/C	72108	Body Bush
72004	Drag Spring	1066846	Ball S/P Cover	1066858	Drive Gear
72006	Drag Knob Under Cap	72084	Ball S/P Cover S/C	72112	Drive Gear ADJ W/S
72008	Under Cap Retainer	1071791	Ball Ass'y	72113	Ball Bearing
72010	Under Cap Retainer S/C	1071799	Line Roller	1071838	Body Cover
72012	Drag Click Spring	1066843	Arm Lever	72117	Body Cover S/C
72014	Drag Clicker	72071	Ball Screw	72119	S/Lever S/P
72015	Spool Ring	1066852	Kick Lever	1071847	IAR Lever
1066864	Drag "D" Washer	1066853	Kick Lever S/P	72122	Stopper Lever S/C
1066865	Drag "A" Washer	1066851	Kick Lever Cover	1071843	Body Cap
1066863	Drag "B" Washer	72088	Ball Bearing	72125	Body Cap S/C
72029	Click Washer	1066855	Bearing W/S	1071823	Handle Ass'y
72030	Click Gear	72091	O/Way Clutch B/B	72128	Rotor Nut Lock S/C
1066840	Main Shaft	72094	Clutch Bush	1066841	Rotor Nut
72038	E - Clip	1066854	Pinion Gear	1066849	Lever Shaft
72040	Rotor "D" Washer	1071831	Body	1066860	B/Bearing Bushing
1071816	Rotor	1071827	Handle Cap Screw	1066867	Bearing Plate
72048	Balance Weight	72102	Screw Cap W/S	1071753	Spool
1066848	Ball Spring	1066861	O/S Gear	1066868	Bearing Plate S/C
		1066862	O/S Slider	1071780	Spool Ass'y