


DIAGRAM



Please specify reel model and part number when ordering parts.

ENDEUR EN4F

PART#	PARTS NAME	PART#	PARTS NAME	PART#	PARTS NAME
1071790	Drag Knob	72057	Bail S/P Shaft	1071830	Handle Cap Screw
72003	Drag Nut	1071815	Bail S/P Cover	72102	Handle Screw Cap W/S
72005	Drag Spring	72060	Bail S/P Cover S/C	72104	O/S Gear
72007	Drag Knob Under Cap	1071798	Bail Ass'y	72106	O/S Slider
72009	Under Cap Retainer	1071801	Line Roller	72107	O/S Slider S/C
72011	Under Cap Retainer S/C	72105	Ball Bearing	72109	Body Bush
72013	Drag Click Spring	72068	Bail W/S	72111	Drive Gear
72014	Drag Clicker	1071806	Arm Lever	72112	Drive Gear ADJ W/S
72016	Spool Ring	72071	Bail Screw	72114	Ball Bearing
72018	Drag "D" Washer	72076	Kick Lever	1071841	Body Cover
72020	Drag "A" Washer	72079	Kick Lever S/P	1071842	Body Cover S/C
72022	Drag "B" Washer	1071811	Kick Lever Cover	72120	S/Lever S/P
1071779	Spool Unit	72084	Kick Lever Cover S/C	1071802	IAR Lever
72029	Click Washer	72085	Bearing Plate S/C	72122	IAR Lever S/C
72031	Click Gear	72087	Bearing Plate	1071845	Body Cap
72035	Main Shaft	72088	Ball Bearing	1071846	Body Cap S/C
72038	E - Clip	72090	Bearing W/S	1071826	Handle Ass'y
72041	Rotor "D" Washer	72092	Q/Way Clutch S/C	72103	Rotor Nut Lock S/C
1071822	Rotor	72094	Clutch Bush	72129	Kick Lever Plate
72050	Balance Weight	72096	Pinion Gear	72130	Pinion Washer
72055	Bail Spring	1071837	Body	72131	B/ Bearing Bushing
		72100	Tail Shaft		